


# 全回路图



## SWITCHES

- SW 001 ----- POWER
- SW 201 (1-6) ----- INPUT SELECTOR (1: ON, 2: OFF)
- SW 201-1, 4 ON --- PHONO
- SW 201-2, 5 ON --- AUX
- SW 201-3, 6 ON --- TUNER
- SW 202 (1-2) ----- TAPE SELECTOR (1: TAPE-1, 2: TAPE-2)
- SW 203 (1-2) ----- MONITOR (1: SOURCE, 2: MONITOR)
- SW 204 (1-2) ----- MODE (1: STEREO, 2: MONO)

## VOLUMES

- VR 201 ----- BALANCE
- VR 202 ----- VOLUME CONTROL
- VR 203 ----- BASS ] TONE CONTROL
- VR 204 ----- TREBLE ]
- VR 301 ----- AC BALANCE ADJUST
- VR 302 ----- DC BALANCE ADJUST
- VR 303 ----- IDLING CURRENT ADJUST

## VACUUM TUBES

- V1 - V4 ----- 12 AX7
- V5 ----- 6A Q8
- V6, V7 ----- 12 AU7
- V8-V11 ----- 6CA 7

## (\*) PCB

- CON.
- ALUM.
- BRON.

